

# 3.3.0 Objective

In this section, you will learn how to ...



## Define Interfering link transmitter ( $I_t$ )

- Tx power
- Antenna characteristics
- Set the emission bandwidth



## Position the VLR vs $I_t$ (i.e. Victim link vs Interfering link)



## Calculate the iRSS



## Relation between Emission bandwidth, reference bandwidth and VLR

Revision #1

Created 2026-04-14 09:52:15 UTC by ECO TECH

Updated 2026-04-14 09:52:36 UTC by ECO TECH