

# 10.3.5 Propagation Model

You can choose the suitable propagation model to be applied when calculating signal loss between the ILT and the VLR. A choice and settings of propagation models are presented in ANNEX 17:.

---

Revision #1

Created 2026-04-21 07:50:42 UTC by ECO TECH

Updated 2026-04-21 07:50:48 UTC by ECO TECH