

3.2.4 Transmitter

Set now the victim link transmitter by selecting the transmitter tab




Figure 74: Selecting the transmitter tab

The parameters should be filled as follows:

- The power is 30 dBm; (#1 of Figure 75)
- An omni-directional antenna of 9 dBi is used;
- The antenna height is 30 m.




Figure 75: Example of setting up the victim link transmitter