

3.2.9 Selecting the victim in the Scenario

Now it's time to create the victim link. The only thing needed is to select a system to be used as victim link as shown in (#1) of Figure 83 under the "scenario" tab.

Note that the frequency field at the "scenario" tab level overwrites what was predefined at "system" tab level (#2).




Figure 83: Setting the system of your choice to be the victim link in the "scenario" tab

Revision #1

Created 2026-04-14 09:37:53 UTC by ECO TECH

Updated 2026-04-14 09:38:25 UTC by ECO TECH