

Introduction

Whether you want to simulate CDMA UL (uplink) or CDMA DL (downlink), you can import from the system library (Figure 186 - (a)), the cellular system you want (Figure 186 - (b)). You can also export the characteristics of your CDMA network to the library for later reuse.




Figure 186: Selection of a CDMA cellular network from the system library

Revision #1

Created 2026-04-17 10:32:57 UTC by ECO TECH

Updated 2026-04-17 10:33:30 UTC by ECO TECH